

Jupiter 3 inch Conduit Canopy Installation Instructions

IMPORTANT: Read all instructions before installing fixtures. Retain for future reference.

SAFETY: For your safety, this fixture must be wired in accordance to local electrical codes and ordinances. All work should be done by a qualified electrician.

WARNING: Make certain power is OFF from the electrical panel before starting installation or attempting any maintenance.

INSTALLATION STEPS:

1. Turn off the power from the electrical panel before starting installation.
2. Pull the power cords and 0-10V wires through the center hole of mounting bracket. Install the mounting bracket onto the outlet box with the supplied screws.(Fig.1)
3. Connect power supply wires to the power feed connectors with wire nuts. Make certain no exposed strands of wire.(Fig.2)
 - A. Connect green ground wire of power supply to green wire of quick connector.
 - B. Connect the white wire of power supply to the white wire of quick connector.
 - C. Connect the black wire of power supply to the black wire of quick connector.
- Remark:** If using 0-10V dimmer,connect dimming wire to the two wire connector by wire nuts. Connect the purple wire (Dim +) to the purple wire(Dim+), Connect the pink wire (Dim-) to the pink wire(Dim-)
4. Remove the appropriate knockout(s) from the surface mount panel to accommodate the conduit entering all sides of the junction box.
5. Installing the surface mount panel onto the mounting bracket with the screws provided.(FIG.3)
6. Select the desired color temperature using the selector switch on the back of the cylinder module. Plug in the quick connector to the cylinder module.(Fig.4)
7. Twist the cylinder module clockwise onto the surface mount panel.(Fig.5)
8. Turn on the power for testing.(Fig.6)

