

INSTRUCTION SHEET RECESSED MOUNT PENDANT

IMPORTANT: Read all instructions before installing LED downlight. Retain the instructions for future reference.

SAFETY: This fixture must be wired in accordance with local electrical codes and ordinances. Carefully observe grounding procedure under installation section. All work should be done by a qualified electrician.

WARNING:

1. Make certain power is OFF from the electrical panel before starting the installation or attempting any maintenance.
2. Do not mix different style fixtures on the same dimmer, not all fixtures will show the same correlated color temperature at the same dimming level.
3. This fixture is suitable for Damp or Dry location indoor.

INSTALLATION STEPS:

1. Turn off the power from the electrical panel before starting installation.
2. Locate a suitable position to place the fixture and open a hole in accordance to the cut-hole dimensions. (Cutout template included).
3. Run the electrical wire from the switch (power supply) through the opening hole and cover of the junction box (use NMD90 Romex or BX cable). (Fig.1)
4. Push the junction box into the hole, then fasten the two screws at the bottom of the junction box to fix it well onto the ceiling. (Fig.2)
5. Unscrew the screw with supplied screw driver and adjust your desired cable length. Then fasten the screws well. (Fig.3)
6. Connect power supply wires to the fixture wires with wire nuts as following. Make certain there are no exposed strands of wire. (Fig.4)
 - A. Connect green ground wire of power supply to green wire of quick connector.
 - B. Connect the white wire of power supply to the white wire of quick connector.
 - C. Connect the black wire of power supply to the black wire of quick connector.
- Remark:** If using 0-10V dimmer, connect dimming wire to the two wire connector by wire nuts. Connect the purple wire (Dim+) to the purple wire (Dim+), Connect the pink wire (Dim-) to the pink wire (Dim-).
7. Place wires back into the junction box and twist the hanging kit onto the junction box. (Fig.5)
8. Choose the required correlated color temperature (CCT) by the CCT switch on the back of the fixture and plug-in the quick connectors to the cylinder module connectors accordingly. (Fig.6)
9. Twist the cylinder module clockwise onto the hanging kit panel. (Fig.7)
10. Once installation is complete, turn on the power to confirm fixtures are working properly.

